

Dell OpenManage™ Server Administrator Messages Reference Guide

Notes and Notices



NOTE: A NOTE indicates important information that helps you make better use of your computer.



NOTICE: A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

Information in this document is subject to change without notice.

© 2003-2004 Dell Inc. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: The *DELL* logo and *Dell OpenManage* are trademarks of Dell Inc.; *Microsoft* and *Windows* are registered trademarks of Microsoft Corporation; *Novell* and *NetWare* are registered trademarks of Novell, Inc.; *Red Hat* is a registered trademark of Red Hat, Inc.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

July 2004

Contents

1 Introduction

Messages Not Described in This Guide	5
Understanding Event Messages	6
Sample Event Message Text	7
Viewing Event Messages	7
Viewing Events in Windows 2000 and Windows Server 2003	8
Viewing Events in NetWare	8
Viewing Events in Red Hat Linux	8
Viewing the Event Information	9
Understanding the Event Description.	9

2 Event Message Reference

Miscellaneous Messages	13
Temperature Sensor Messages	15
Cooling Device Messages	17
Voltage Sensor Messages	19
Current Sensor Messages	21
Chassis Intrusion Messages	24
Redundancy Unit Messages	26
Power Supply Messages	28
Memory Device Messages	31
Fan Enclosure Messages	32
AC Power Cord Messages	34
Hardware Log Sensor Messages	35
Processor Sensor Messages	36

Index	39
-------	----

Tables

Table 1-1.	Event Description Reference	9
Table 2-1.	Miscellaneous Messages	13
Table 2-2.	Temperature Sensor Messages	15
Table 2-3.	Cooling Device Messages	18
Table 2-4.	Voltage Sensor Messages	19
Table 2-5.	Current Sensor Messages	22
Table 2-6.	Chassis Intrusion Messages	25
Table 2-7.	Redundancy Unit Messages	27
Table 2-8.	Power Supply Messages	29
Table 2-9.	Memory Device Messages	32
Table 2-10.	Fan Enclosure Messages	33
Table 2-11.	AC Power Cord Messages	34
Table 2-12.	Hardware Log Sensor Messages	35
Table 2-13.	Processor Sensor Messages	37

Introduction

Dell OpenManage Server Administrator produces event messages stored primarily in the operating system or Server Administrator event logs and sometimes in SNMP traps. This document describes the event messages created by Server Administrator version 1.8.1 or later and displayed in the Server Administrator Alert log.

Server Administrator creates events in response to sensor status changes and other monitored parameters. The Server Administrator event monitor uses these status change events to add descriptive messages to the operating system event log or the Server Administrator Alert log.

Each event message that Server Administrator adds to the Alert log consists of a unique identifier called the event ID for a specific event source category and a descriptive message. The event message includes the severity, cause of the event, and other relevant information, such as the event location and the monitored item's previous state.

Tables provided in this guide list all Server Administrator event IDs in numeric order. Each entry includes the event ID's corresponding description, severity level, and cause. Message text in angle brackets (for example, *<State>*) describes the event-specific information provided by the Server Administrator.

Messages Not Described in This Guide

This guide describes only event messages created by Server Administrator and displayed in the Server Administrator Alert log. For information on other messages produced by your system, consult one of the following sources:

- Your system's *Installation and Troubleshooting Guide*
- Other system documentation
- Operating system documentation
- Application program documentation

For RAID messages, see the *Dell OpenManage Array Manager User's Guide*.

Understanding Event Messages

This section describes the various types of event messages generated by the Server Administrator. When an event occurs on your system, the Server Administrator sends information about one of the following event types to the systems management console:

- **Information** — An event that describes the successful operation of a unit, such as a power supply turning on or a sensor reading returning to normal.
- **Warning** — An event that is not necessarily significant, but may indicate a possible future problem, such as crossing a warning threshold.
- **Error** — A significant event that indicates actual or imminent loss of data or loss of function, such as crossing a failure threshold or a hardware failure.

The Server Administrator generates events based on status changes in the following sensors:

- **Temperature Sensor** — Helps protect critical components by alerting the systems management console when temperatures become too high inside a chassis; also monitors a variety of locations in the chassis and in any attached systems.
- **Fan Sensor** — Monitors fans in various locations in the chassis and in any attached systems.
- **Voltage Sensor** — Monitors voltages across critical components in various chassis locations and in any attached systems.
- **Current Sensor** — Monitors the current (or amperage) output from the power supply (or supplies) in the chassis and in any attached systems.
- **Chassis Intrusion Sensor** — Monitors intrusion into the chassis and any attached systems.
- **Redundancy Unit Sensor** — Monitors redundant units (critical units such as fans, AC power cords, or power supplies) within the chassis; also monitors the chassis and any attached systems. For example, redundancy allows a second or *n*th fan to keep the chassis components at a safe temperature when another fan has failed. Redundancy is normal when the intended number of critical components are operating. Redundancy is degraded when a component fails but others are still operating. Redundancy is lost when there is one less critical redundancy device than required.
- **Power Supply Sensor** — Monitors power supplies in the chassis and in any attached systems.
- **Memory Prefailure Sensor** — Monitors memory modules by counting the number of ECC memory corrections.
- **Fan Enclosure Sensor** — Monitors protective fan enclosures by detecting their removal from and insertion into the system, and by measuring how long a fan enclosure is absent from the chassis. This sensor monitors the chassis and any attached systems.
- **AC Power Cord Sensor** — Monitors the presence of AC power for an AC power cord.
- **Hardware Log Sensor** — Monitors the size of a hardware log.
- **Processor Sensor** — Monitors the processor status in the system.

Sample Event Message Text

The following example shows the format of the event messages logged by Server Administrator.

```
EventID: 1000
Source: Server Administrator
Category: Instrumentation Service
Type: Information
Date and Time: Mon Oct 21 10:38:00 2002
Computer: <computer name>
Description:
Server Administrator starting
Data: Bytes in Hex
```

Viewing Event Messages

In Server Administrator, an event log is used to record information about important events. You can view the event log using an event viewer. Each operating system's event viewer accesses the applicable operating system event log.

The location of the event log file depends on the operating system you are using.

- In the Microsoft® Windows® 2000 Advanced Server and Windows Server 2003 operating systems, messages are logged to the system event log and optionally to a unicode text file, **dcsys32.log** (viewable using Notepad), that is located in the *install_path\omsa\log* directory. The default *install_path* is **C:\Program Files\Dell\OpenManage**.
- In the Novell® NetWare® versions 5.x and 6.x operating systems, messages are logged to a text file, **DCSYS32.LOG**, (viewable using a unicode text editor from a client attached to the system), that is located in the **\system\dell\omanage\omsa\log** directory.
- In the Red Hat® Linux operating system, messages are logged to the system log file. The default name of the system log file is **/var/log/messages**. You can view the messages file using a text editor such as vi or emacs.



NOTE: Logging messages to a unicode text file is optional. By default, the feature is disabled. To enable this feature, modify the **Event Manager** section of the **dcemdy32.ini** file as follows:


- In Windows, locate the file at *install_path\dataeng\ini* and set *UnitextLog.enabled=True*. The default *install_path* is **C:\Program Files\Dell\OpenManage**. Restart the **Systems Management Event Manager** service.
- In Red Hat Linux, locate the file at **/usr/lib/dell/openmanage/dataeng/ini** and set *UnitextLog.enabled=True*. Issue the **service dataeng restart** command to restart the systems management event manager service. This will also restart the systems management data manager and SNMP services.

- In Novell NetWare, locate the file at `\system\dell\omanage\dataeng\ini` and set `UnitextLog.enabled=True`. Issue the **omstop** command and then issue the **omstart** command to restart the systems management event manager service. This will also restart the systems management data manager and SNMP services.

The following subsections explain how to open the Windows 2000, Windows Server 2003, NetWare, and Red Hat Linux event viewers.

Viewing Events in Windows 2000 and Windows Server 2003

- 1 Click the **Start** button, point to **Settings**, and click **Control Panel**.
- 2 Double-click **Administrative Tools**, and then double-click **Event Viewer**.
- 3 In the **Event Viewer** window, click the **Tree** tab and then click **System Log**. The **System Log** window displays a list of recently logged events.
- 4 To view the details of an event, double-click one of the event items.

 **NOTE:** You can also view the separate event log file by editing the `dcsys32.log` file in the `install_path\omsa\log` directory. The default `install_path` is `C:\Program Files\Dell\OpenManage`.


Viewing Events in NetWare

- 1 Using a Windows system, map a drive to the `\nwserver\sys` directory, where `nwserver` is the name of your NetWare system.
- 2 From the mapped drive, locate the `DCSYS32.LOG` file in the `\system\dell\omanage\omsa\log` directory.
- 3 View the `DCSYS32.LOG` file with Notepad or any other unicode-capable text editor.

Viewing Events in Red Hat Linux

- 1 Log in as **root**.
- 2 Use a text editor such as vi or emacs to view the file named `/var/log/messages`.

The following example shows the Linux message log, `/var/log/messages`. The text in boldface type indicates the message text.

 **NOTE:** These messages are typically displayed as one long line. In the following example, the message is displayed using line breaks to help you see the message text more clearly.

...

```
Feb 6 14:20:51 server01 Server Administrator: Instrumentation
Service EventID: 1000
Server Administrator starting
```

Feb 6 14:20:51 server01 Server Administrator: Instrumentation
Service EventID: 1001

Server Administrator startup complete

Feb 6 14:21:21 server01 Server Administrator: Instrumentation
Service EventID: 1254 **Chassis intrusion detected Sensor location:
Main chassis intrusion Chassis location: Main System Chassis
Previous state was: OK (Normal) Chassis intrusion state: Open**

Feb 6 14:21:51 server01 Server Administrator: Instrumentation
Service EventID: 1252 **Chassis intrusion returned to normal Sensor
location: Main chassis intrusion Chassis location: Main System
Chassis Previous state was: Critical (Failed) Chassis intrusion
state: Closed**

Viewing the Event Information

The event log for each operating system contains some or all of the following information:

- **Date** — The date the event occurred.
- **Time** — The local time the event occurred.
- **Type** — A classification of the event severity: Information, Warning, or Error.
- **User** — The name of the user on whose behalf the event occurred.
- **Computer** — The name of the system where the event occurred.
- **Source** — The software that logged the event.
- **Category** — The classification of the event by the event source.
- **Event ID** — The number identifying the particular event type.
- **Description** — A description of the event. The format and contents of the event description vary, depending on the event type.

Understanding the Event Description

Table 1-1 lists in alphabetical order each line item that may appear in the event description.

Table 1-1. Event Description Reference

Description Line Item	Explanation
Action performed was: <Action>	Specifies the action that was performed, for example: Action performed was: Power cycle
Action requested was: <Action>	Specifies the action that was requested, for example: Action requested was: Reboot, shutdown OS first

Table 1-1. Event Description Reference (*continued*)

Description Line Item	Explanation
<Additional power supply status information>	Specifies information pertaining to the event, for example: Power supply input AC is off, Power supply POK (power OK) signal is not normal, Power supply is turned off
Chassis intrusion state: <Intrusion state>	Specifies the chassis intrusion state (open or closed), for example: Chassis intrusion state: Open
Chassis location: <Name of chassis>	Specifies name of the chassis that generated the message, for example: Chassis location: Main System Chassis
Configuration error type: <type of configuration error>	Specifies the type of configuration error that occurred, for example: Configuration error type: Revision mismatch
Current sensor value (in Amps): <Reading>	Specifies the current sensor value in amps, for example: Current sensor value (in Amps): 7.853
Date and time of action: <Date and time>	Specifies the date and time the action was performed, for example: Date and time of action: Sat Jun 12 16:20:33 2004
Discrete current state: <State>	Specifies the state of the current sensor, for example: Discrete current state: Good
Discrete temperature state: <State>	Specifies the state of the temperature sensor, for example: Discrete temperature state: Good
Discrete voltage state: <State>	Specifies the state of the voltage sensor, for example: Discrete voltage state: Good
Fan sensor value: <Reading>	Specifies the fan speed in revolutions per minute (RPM) or On/Off, for example: Fan sensor value (in RPM): 2600 Fan sensor value: Off
Log type: <Log type>	Specifies the type of hardware log, for example: Log type: ESM

Table 1-1. Event Description Reference (continued)


Description Line Item	Explanation
Memory device bank location: <Bank name in chassis>	<p>Specifies the name of the memory bank in the system that generated the message, for example:</p> <p>Memory device bank location: Bank_1</p>
Memory device location: <Device name in chassis>	<p>Specifies the location of the memory module in the chassis, for example:</p> <p>Memory device location: DIMM_A</p>
Number of devices required for full redundancy: <Number>	<p>Specifies the number of power supply or cooling devices required to achieve full redundancy, for example:</p> <p>Number of devices required for full redundancy: 4</p>
Possible memory module event cause: <list of causes>	<p>Specifies a list of possible causes for the memory module event, for example:</p> <p>Possible memory module event cause: Single bit warning error rate exceeded</p> <p>Single bit error logging disabled</p>
Power Supply type: <type of power supply>	<p>Specifies the type of power supply, for example:</p> <p>Power Supply type: VRM</p>
Previous redundancy state was: <State>	<p>Specifies the status of the previous redundancy message, for example:</p> <p>Previous redundancy state was: Lost</p>
Previous state was: <State>	<p>Specifies the previous state of the sensor, for example:</p> <p>Previous state was: OK (Normal)</p>
Processor sensor status: <status>	<p>Specifies the status of the processor sensor, for example:</p> <p>Processor sensor status: Configuration error</p>
Redundancy unit: <Redundancy location in chassis>	<p>Specifies the location of the redundant power supply or cooling unit in the chassis, for example:</p> <p>Redundancy unit: Fan Enclosure</p>
Sensor location: <Location in chassis>	<p>Specifies the location of the sensor in the specified chassis, for example:</p> <p>Sensor location: CPU1</p>

Table 1-1. Event Description Reference (continued)

Description Line Item	Explanation
Temperature sensor value: <Reading>	Specifies the temperature in degrees Celsius, for example: Temperature sensor value (in degrees Celsius): 30
Voltage sensor value (in Volts): <Reading>	Specifies the voltage sensor value in volts, for example: Voltage sensor value (in Volts): 1.693

Event Message Reference

The following tables lists in numerical order each event ID and its corresponding description, along with its severity and cause.

 **NOTE:** For corrective actions, see the appropriate documentation.

Miscellaneous Messages

Miscellaneous messages in Table 2-1 indicate that certain alert systems are up and working.

Table 2-1. Miscellaneous Messages

Event ID	Description	Severity	Cause
0000	Log was cleared	Information	User cleared the log from Server Administrator.
0001	Log backup created	Information	The log was full, copied to backup, and cleared.
1000	Server Administrator starting	Information	Server Administrator is beginning to initialize.
1001	Server Administrator startup complete	Information	Server Administrator completed its initialization.
1002	A system BIOS update has been scheduled for the next reboot	Information	The user has chosen to update the flash basic input/output system (BIOS).
1003	A previously scheduled system BIOS update has been canceled	Information	The user decides to cancel the flash BIOS update, or an error occurs during the flash.

Table 2-1. Miscellaneous Messages (*continued*)

Event ID	Description	Severity	Cause
1004	Thermal shutdown protection has been initiated	Error	This message is generated when a system is configured for thermal shutdown due to an error event. If a temperature sensor reading exceeds the error threshold for which the system is configured, the operating system shuts down and the system powers off. This event may also be initiated on certain systems when a fan enclosure is removed from the system for an extended period of time.
1005	SMBIOS data is absent	Warning	The system management BIOS does not contain a valid system management BIOS version 2.2 or higher, or the BIOS is corrupted.
1006	Automatic System Recovery (ASR) action was performed Action performed was: <Action> Date and time of action: <Date and time>	Error	This message is generated when an automatic system recovery action is performed due to a hung operating system. The action performed and the time of action are provided.
1007	User initiated host system control action Action requested was: <Action>	Information	User requested a host system control action to reboot, power off, or power cycle the system. Alternatively the user had indicated protective measures to be initiated in the event of a thermal shutdown.
1008	Systems Management Data Manager Started	Information	Systems Management Data Manager services were started.
1009	Systems Management Data Manager Stopped	Information	Systems Management Data Manager services were stopped.

Temperature Sensor Messages

Temperature sensors listed in Table 2-2 help protect critical components by alerting the systems management console when temperatures become too high inside a chassis. The temperature sensor messages use additional variables: sensor location, chassis location, previous state, and temperature sensor value or state.

Table 2-2. Temperature Sensor Messages

Event ID	Description	Severity	Cause
1050	<p>Temperature sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Information	A temperature sensor on the backplane board, system board, or the carrier in the specified system failed. The sensor location, chassis location, previous state, and temperature sensor value are provided.
1051	<p>Temperature sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Information	A temperature sensor on the backplane board, system board, or drive carrier in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal temperature sensor value are provided.

Table 2-2. Temperature Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1052	<p>Temperature sensor returned to a normal value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Information	A temperature sensor on the backplane board, system board, or drive carrier in the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.
1053	<p>Temperature sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Warning	A temperature sensor on the backplane board, system board, or drive carrier in the specified system exceeded its warning threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.

Table 2-2. Temperature Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1054	<p>Temperature sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Error	A temperature sensor on the backplane board, system board, or drive carrier in the specified system exceeded its failure threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.
1055	<p>Temperature sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Error	A temperature sensor on the backplane board, system board, or drive carrier in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and temperature sensor value are provided.

Cooling Device Messages

Cooling device sensors listed in Table 2-3 monitor how well a fan is functioning. Cooling device messages provide status and warning information for fans in a particular chassis.

Table 2-3. Cooling Device Messages

Event ID	Description	Severity	Cause
1100	<p>Fan sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Information	A fan sensor in the specified system is not functioning. The sensor location, chassis location, previous state, and fan sensor value are provided.
1101	<p>Fan sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Information	A fan sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal fan sensor value are provided.
1102	<p>Fan sensor returned to a normal value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Information	A fan sensor reading on the specified system returned to a valid range after crossing a warning threshold. The sensor location, chassis location, previous state, and fan sensor value are provided.
1103	<p>Fan sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Warning	A fan sensor reading in the specified system exceeded a warning threshold. The sensor location, chassis location, previous state, and fan sensor value are provided.

Table 2-3. Cooling Device Messages (*continued*)

Event ID	Description	Severity	Cause
1104	<p>Fan sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Error	A fan sensor in the specified system detected the failure of one or more fans. The sensor location, chassis location, previous state, and fan sensor value are provided.
1105	<p>Fan sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Fan sensor value: <Reading></p>	Error	A fan sensor detected an error from which it cannot recover. The sensor location, chassis location, previous state, and fan sensor value are provided.

Voltage Sensor Messages

Voltage sensors listed in Table 2-4 monitor the number of volts across critical components. Voltage sensor messages provide status and warning information for voltage sensors in a particular chassis.

Table 2-4. Voltage Sensor Messages

Event ID	Description	Severity	Cause
1150	<p>Voltage sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Information	A voltage sensor in the specified system failed. The sensor location, chassis location, previous state, and voltage sensor value are provided.

Table 2-4. Voltage Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1151	<p>Voltage sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Information	A voltage sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal voltage sensor value are provided.
1152	<p>Voltage sensor returned to a normal value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Information	A voltage sensor in the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.
1153	<p>Voltage sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Warning	A voltage sensor in the specified system exceeded its warning threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.

Table 2-4. Voltage Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1154	<p>Voltage sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Error	A voltage sensor in the specified system exceeded its failure threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.
1155	<p>Voltage sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Error	A voltage sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and voltage sensor value are provided.

Current Sensor Messages

Current sensors listed in Table 2-5 measure the amount of current (in amperes) that is traversing critical components. Current sensor messages provide status and warning information for current sensors in a particular chassis.

Table 2-5. Current Sensor Messages

Event ID	Description	Severity	Cause
1200	<p>Current sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Information	A current sensor on the power supply for the specified system failed. The sensor location, chassis location, previous state, and current sensor value are provided.
1201	<p>Current sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Information	A current sensor on the power supply for the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal current sensor value are provided.

Table 2-5. Current Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1202	<p>Current sensor returned to a normal value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Information	<p>A current sensor on the power supply for the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and current sensor value are provided.</p>
1203	<p>Current sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Warning	<p>A current sensor on the power supply for the specified system exceeded its warning threshold. The sensor location, chassis location, previous state, and current sensor value are provided.</p>

Table 2-5. Current Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1204	<p>Current sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Error	A current sensor on the power supply for the specified system exceeded its failure threshold. The sensor location, chassis location, previous state, and current sensor value are provided.
1205	<p>Current sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Error	A current sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and current sensor value are provided.

Chassis Intrusion Messages

Chassis intrusion messages listed in Table 2-6 are a security measure. Chassis intrusion means that someone is opening the cover to a system's chassis. Alerts are sent to prevent unauthorized removal of parts from a chassis.

Table 2-6. Chassis Intrusion Messages

Event ID	Description	Severity	Cause
1250	<p>Chassis intrusion sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Chassis intrusion state: <Intrusion state></p>	Information	A chassis intrusion sensor in the specified system failed. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1251	<p>Chassis intrusion sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Chassis intrusion state: <Intrusion state></p>	Information	A chassis intrusion sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1252	<p>Chassis intrusion returned to normal</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Chassis intrusion state: <Intrusion state></p>	Information	A chassis intrusion sensor in the specified system detected that a cover was opened while the system was operating but has since been replaced. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1253	<p>Chassis intrusion in progress</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Chassis intrusion state: <Intrusion state></p>	Warning	A chassis intrusion sensor in the specified system detected that a system cover is currently being opened and the system is operating. The sensor location, chassis location, previous state, and chassis intrusion state are provided.

Table 2-6. Chassis Intrusion Messages (*continued*)

Event ID	Description	Severity	Cause
1254	Chassis intrusion detected Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Error	A chassis intrusion sensor in the specified system detected that the system cover was opened while the system was operating. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1255	Chassis intrusion sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Error	A chassis intrusion sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and chassis intrusion state are provided.

Redundancy Unit Messages

Redundancy means that a system chassis has more than one of certain critical components. Fans and power supplies, for example, are so important for preventing damage or disruption of a computer system that a chassis may have “extra” fans or power supplies installed. Redundancy allows a second or *n*th fan to keep the chassis components at a safe temperature when the primary fan has failed. Redundancy is normal when the intended number of critical components are operating. Redundancy is degraded when a component fails but others are still operating. Redundancy is lost when the number of components functioning falls below the redundancy threshold. Table 2-7 lists the redundancy unit messages.

The number of devices required for full redundancy is provided as part of the message when applicable for the redundancy unit and the platform. For details on redundancy computation, see the respective platform documentation.

Table 2-7. Redundancy Unit Messages

Event ID	Description	Severity	Cause
1300	<p>Redundancy sensor has failed</p> <p>Redundancy unit: <Redundancy location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous redundancy state was: <State></p>	Information	A redundancy sensor in the specified system failed. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1301	<p>Redundancy sensor value unknown</p> <p>Redundancy unit: <Redundancy location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous redundancy state was: <State></p>	Information	A redundancy sensor in the specified system could not obtain a reading. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1302	<p>Redundancy not applicable</p> <p>Redundancy unit: <Redundancy location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous redundancy state was: <State></p>	Information	A redundancy sensor in the specified system detected that a unit was not redundant. The redundancy location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1303	<p>Redundancy is offline</p> <p>Redundancy unit: <Redundancy location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous redundancy state was: <State></p>	Information	A redundancy sensor in the specified system detected that a redundant unit is offline. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.

Table 2-7. Redundancy Unit Messages (*continued*)

Event ID	Description	Severity	Cause
1304	Redundancy regained Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Information	A redundancy sensor in the specified system detected that a “lost” redundancy device has been reconnected or replaced; full redundancy is in effect. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1305	Redundancy degraded Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Warning	A redundancy sensor in the specified system detected that one of the components of the redundancy unit has failed but the unit is still redundant. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1306	Redundancy lost Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Warning or Error (depending on the number of units that are functional)	A redundancy sensor in the specified system detected that one of the components in the redundant unit has been disconnected, has failed, or is not present. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.

Power Supply Messages

Power supply sensors monitor how well a power supply is functioning. Power supply messages listed in Table 2-8 provide status and warning information for power supplies present in a particular chassis.

Table 2-8. Power Supply Messages

Event ID	Description	Severity	Cause
1350	<p>Power supply sensor has failed</p> <p>Sensor location: <i><Location in chassis></i></p> <p>Chassis location: <i><Name of chassis></i></p> <p>Previous state was: <i><State></i></p> <p>Power Supply type: <i><type of power supply></i></p> <p><i><Additional power supply status information></i></p> <p>If in configuration error state:</p> <p>Configuration error type: <i><type of configuration error></i></p>	Information	<p>A power supply sensor in the specified system failed. The sensor location, chassis location, previous state, and additional power supply status information are provided.</p>
1351	<p>Power supply sensor value unknown</p> <p>Sensor location: <i><Location in chassis></i></p> <p>Chassis location: <i><Name of chassis></i></p> <p>Previous state was: <i><State></i></p> <p>Power Supply type: <i><type of power supply></i></p> <p><i><Additional power supply status information></i></p> <p>If in configuration error state:</p> <p>Configuration error type: <i><type of configuration error></i></p>	Information	<p>A power supply sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and additional power supply status information are provided.</p>

Table 2-8. Power Supply Messages (*continued*)


Event ID	Description	Severity	Cause
1352	<p>Power supply returned to normal</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Information	A power supply has been reconnected or replaced. The sensor location, chassis location, previous state, and additional power supply status information are provided.
1353	<p>Power supply detected a warning</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Warning	A power supply sensor reading in the specified system exceeded a user-definable warning threshold. The sensor location, chassis location, previous state, and additional power supply status information are provided.

Table 2-8. Power Supply Messages (*continued*)

Event ID	Description	Severity	Cause
1354	<p>Power supply detected a failure</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Error	<p>A power supply has been disconnected or has failed. The sensor location, chassis location, previous state, and additional power supply status information are provided.</p>
1355	<p>Power supply sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Error	<p>A power supply sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and additional power supply status information are provided.</p>

Memory Device Messages

Memory device messages listed in Table 2-9 provide status and warning information for memory modules present in a particular system. Memory devices determine health status by monitoring the ECC memory correction rate and the type of memory events that have occurred.

 **NOTE:** A critical status does not always indicate a system failure or loss of data. In some instances, the system has exceeded the ECC correction rate. Although the system continues to function, you should perform system maintenance as described in Table 2-9.


 **NOTE:** In Table 2-9, *<status>* can be either *critical* or *non-critical*.

Table 2-9. Memory Device Messages

Event ID	Description	Severity	Cause
1403	Memory device status is <i><status></i> Memory device location: <i><location in chassis></i> Possible memory module event cause: <i><list of causes></i>	Warning	A memory device correction rate exceeded an acceptable value. The memory device status and location are provided.
1404	Memory device status is <i><status></i> Memory device location: <i><location in chassis></i> Possible memory module event cause: <i><list of causes></i>	Error	A memory device correction rate exceeded an acceptable value, a memory spare bank was activated, or a multibit ECC error occurred. The system continues to function normally (except for a multibit error). Replace the memory module identified in the message during the system's next scheduled maintenance. Clear the memory error on multibit ECC error. The memory device status and location are provided.

Fan Enclosure Messages

Some systems are equipped with a protective enclosure for fans. Fan enclosure messages listed in Table 2-10 monitor whether foreign objects are present in an enclosure and how long a fan enclosure is missing from a chassis.

Table 2-10. Fan Enclosure Messages

Event ID	Description	Severity	Cause
1450	<p>Fan enclosure sensor has failed</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p>	Information	The fan enclosure sensor in the specified system failed. The sensor location and chassis location are provided.
1451	<p>Fan enclosure sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p>	Information	The fan enclosure sensor in the specified system could not obtain a reading. The sensor location and chassis location are provided.
1452	<p>Fan enclosure inserted into system</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p>	Information	A fan enclosure has been inserted into the specified system. The sensor location and chassis location are provided.
1453	<p>Fan enclosure removed from system</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p>	Warning	A fan enclosure has been removed from the specified system. The sensor location and chassis location are provided.
1454	<p>Fan enclosure removed from system for an extended amount of time</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p>	Error	A fan enclosure has been removed from the specified system for a user-definable length of time. The sensor location and chassis location are provided.

Table 2-10. Fan Enclosure Messages (*continued*)

Event ID	Description	Severity	Cause
1455	Fan enclosure sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	A fan enclosure sensor in the specified system detected an error from which it cannot recover. The sensor location and chassis location are provided.

AC Power Cord Messages

AC power cord messages listed in Table 2-11 provide status and warning information for power cords that are part of an AC power switch, if your system supports AC switching.

Table 2-11. AC Power Cord Messages

Event ID	Description	Severity	Cause
1500	AC power cord sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	An AC power cord sensor in the specified system failed. The AC power cord status cannot be monitored. The sensor location and chassis location information are provided.
1501	AC power cord is not being monitored Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	The AC power cord status is not being monitored. This occurs when a system's expected AC power configuration is set to nonredundant . The sensor location and chassis location information are provided.
1502	AC power has been restored Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	An AC power cord that did not have AC power has had the power restored. The sensor location and chassis location information are provided.

Table 2-11. AC Power Cord Messages (*continued*)

Event ID	Description	Severity	Cause
1503	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Warning	An AC power cord has lost its power, but there is sufficient redundancy to classify this as a warning. The sensor location and chassis location information are provided.
1504	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	An AC power cord has lost its power, and lack of redundancy requires this to be classified as an error. The sensor location and chassis location information are provided.
1505	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	An AC power cord sensor in the specified system failed. The AC power cord status cannot be monitored. The sensor location and chassis location information are provided.

Hardware Log Sensor Messages

Hardware logs provide hardware status messages to systems management software. On certain systems, the hardware log is implemented as a circular queue. When the log becomes full, the oldest status messages are overwritten when new status messages are logged. On some systems, the log is not circular. On these systems, when the log becomes full, subsequent hardware status messages are lost. Hardware log sensor messages listed in Table 2-12 provide status and warning information about the noncircular logs that may fill up, resulting in lost status messages.

Table 2-12. Hardware Log Sensor Messages

Event ID	Description	Severity	Cause
1550	Log monitoring has been disabled Log type: <Log type>	Information	A hardware log sensor in the specified system is disabled. The log type information is provided.

Table 2-12. Hardware Log Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1551	Log status is unknown Log type: <Log type>	Information	A hardware log sensor in the specified system could not obtain a reading. The log type information is provided.
1552	Log size is no longer near or at capacity Log type: <Log type>	Information	The hardware log on the specified system is no longer near or at its capacity, usually as the result of clearing the log. The log type information is provided.
1553	Log size is near or at capacity Log type: <Log type>	Warning	The size of a hardware log on the specified system is near or at the capacity of the hardware log. The log type information is provided.
1554	Log size is full Log type: <Log type>	Error	The size of a hardware log on the specified system is full. The log type information is provided.
1555	Log sensor has failed Log type: <Log type>	Error	A hardware log sensor in the specified system failed. The hardware log status cannot be monitored. The log type information is provided.

Processor Sensor Messages

Processor sensors monitor how well a processor is functioning. Processor messages listed in Table 2-13 provide status and warning information for processors in a particular chassis.

Table 2-13. Processor Sensor Messages

Event ID	Description	Severity	Cause
1600	<p>Processor sensor has failed</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Information	A processor sensor in the specified system is not functioning. The sensor location, chassis location, previous state and processor sensor status are provided.
1601	<p>Processor sensor value unknown</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Information	A processor sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state and processor sensor status are provided.
1602	<p>Processor sensor returned to a normal value</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Information	A processor sensor in the specified system transitioned back to a normal state. The sensor location, chassis location, previous state and processor sensor status are provided.
1603	<p>Processor sensor detected a warning value</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Warning	A processor sensor in the specified system is in a throttled state. The sensor location, chassis location, previous state and processor sensor status are provided.

Table 2-13. Processor Sensor Messages (*continued*)

Event ID	Description	Severity	Cause
1604	<p>Processor sensor detected a failure value</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Error	<p>A processor sensor in the specified system is disabled, has a configuration error, or experienced a thermal trip. The sensor location, chassis location, previous state and processor sensor status are provided.</p>
1605	<p>Processor sensor detected a non-recoverable value</p> <p>Sensor Location: <Location in chassis></p> <p>Chassis Location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Processor sensor status: <status></p>	Error	<p>A processor sensor in the specified system has failed. The sensor location, chassis location, previous state and processor sensor status are provided.</p>

Index

Numerics

0000, 13	1151, 20	1352, 30
0001, 13	1152, 20	1353, 30
1000, 13	1153, 20	1354, 31
1001, 13	1154, 21	1355, 31
1002, 13	1155, 21	1403, 32
1003, 13	1200, 22	1404, 32
1004, 14	1201, 22	1450, 33
1005, 14	1202, 23	1451, 33
1006, 14	1203, 23	1452, 33
1007, 14	1204, 24	1453, 33
1008, 14	1205, 24	1454, 33
1009, 14	1250, 25	1455, 34
1050, 15	1251, 25	1500, 34
1051, 15	1252, 25	1501, 34
1052, 16	1253, 25	1502, 34
1053, 16	1254, 26	1503, 35
1054, 17	1255, 26	1504, 35
1055, 17	1300, 27	1505, 35
1100, 18	1301, 27	1550, 35
1101, 18	1302, 27	1551, 36
1102, 18	1303, 27	1552, 36
1103, 18	1304, 28	1553, 36
1104, 19	1305, 28	1554, 36
1105, 19	1306, 28	1555, 36
1150, 19	1350, 29	1600, 37
	1351, 29	1601, 37

1602, 37
1603, 37
1604, 38
1605, 38

A

A previously scheduled system BIOS update has been canceled, 13
A system BIOS update has been scheduled for the next reboot, 13
AC power cord is not being monitored, 34
AC power cord messages, 34
AC power cord sensor, 6
AC power cord sensor has failed, 34
AC power has been lost, 35
AC power has been restored, 34
Automatic System Recovery (ASR) action was performed, 14

C

Chassis intrusion detected, 26
Chassis intrusion in progress, 25
chassis intrusion messages, 24

Chassis intrusion returned to normal, 25
chassis intrusion sensor, 6
Chassis intrusion sensor detected a non-recoverable value, 26
Chassis intrusion sensor has failed, 25
Chassis intrusion sensor value unknown, 25
cooling device messages, 17
current sensor, 6
Current sensor detected a failure value, 24
Current sensor detected a non-recoverable value, 24
Current sensor detected a warning value, 23
Current sensor has failed, 22
current sensor messages, 21
Current sensor returned to a normal value, 23
Current sensor value unknown, 22

E

event description reference, 9

F

Fan enclosure inserted into system, 33
fan enclosure messages, 32

Fan enclosure removed from system, 33
Fan enclosure removed from system for an extended amount of time, 33
fan enclosure sensor, 6
Fan enclosure sensor detected a non-recoverable value, 34
Fan enclosure sensor has failed, 33
Fan enclosure sensor value unknown, 33
fan sensor, 6
Fan sensor detected a failure value, 19
Fan sensor detected a non-recoverable value, 19
Fan sensor detected a warning value, 18
Fan sensor has failed, 18
Fan sensor returned to a normal value, 18
Fan sensor value unknown, 18

H

hardware log sensor, 6

L

Log backup created, 13
Log monitoring has been disabled, 35

Log size is near or at capacity, 36
Log size returned to a normal level, 36
Log status is unknown, 36
Log was cleared, 13

M

Memory device ECC
Correctable error count crossed a warning threshold, 32
Memory device ECC
Correctable error count sensor crossed a failure threshold, 32
memory device messages, 31
Memory device monitoring has been disabled, 32
memory prefailure sensor, 6
messages
AC power cord, 34
chassis intrusion, 24
cooling device, 17
current sensor, 21
fan enclosure, 32
memory device, 31
miscellaneous, 13
power supply, 28
processor sensor, 36
redundancy unit, 26
temperature sensor, 15
voltage sensor, 19

P

Power supply detected a failure, 31
Power supply detected a warning, 30
power supply messages, 28
Power supply returned to normal, 30
power supply sensor, 6
Power supply sensor detected a non-recoverable value, 31
Power supply sensor has failed, 29
Power supply sensor value unknown, 29
processor sensor, 6
Processor sensor detected a failure value, 38
Processor sensor detected a non-recoverable value, 38
Processor sensor detected a warning value, 37
Processor sensor has failed, 37
Processor sensor returned to a normal state, 37
Processor sensor value unknown, 37

R

Redundancy degraded, 28
Redundancy is offline, 27
Redundancy lost, 28

Redundancy not applicable, 27
Redundancy regained, 28
Redundancy sensor has failed, 27
Redundancy sensor value unknown, 27
redundancy unit messages, 26
redundancy unit sensor, 6

S

sensor
AC power cord, 6
chassis intrusion, 6
current, 6
fan, 6
fan enclosure, 6
hardware log, 6
memory prefailure, 6
power supply, 6, 36
processor, 6, 36
redundancy unit, 6
temperature, 6
voltage, 6
Server Administrator starting, 13
Server Administrator startup complete, 13
SMBIOS data is absent, 14
system management data manager started, 14
system management data manager stopped, 14

T

- temperature sensor, 6
- Temperature sensor detected a failure value, 17
- Temperature sensor detected a non-recoverable value, 17
- Temperature sensor detected a warning value, 16
- Temperature sensor has failed, 15
- temperature sensor messages, 15
- Temperature sensor returned to a normal value, 16
- Temperature sensor value unknown, 15
- Thermal shutdown protection has been initiated, 14
- voltage sensor, 6
- Voltage sensor detected a failure value, 21
- Voltage sensor detected a non-recoverable value, 21
- Voltage sensor detected a warning value, 20
- Voltage sensor has failed, 19
- voltage sensor messages, 19
- Voltage sensor returned to a normal value, 20
- Voltage sensor value unknown, 20

U

- understanding
 - event description, 9
- User initiated host system reset, 14

V

- viewing
 - event information, 9
 - event messages, 7
 - events in NetWare, 8
 - events in Red Hat Linux, 8
 - events in Windows 2000, 8