

Dell™ Dimension™ Systems

SETUP GUIDE

Notes, Notices, and Cautions

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold type or in italic type. These blocks are notes, notices, and cautions, and they are used as follows:



NOTE: A NOTE indicates important information that helps you make better use of your computer system.

NOTICE: A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



CAUTION: A CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**Information in this document is subject to change without notice.
© 1999 Dell Computer Corporation. All rights reserved.**

Reproduction in any manner whatsoever without the written permission of Dell Computer Corporation is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, *Be Direct*, and *Dimension* are trademarks of Dell Computer Corporation; *Microsoft*, *Windows*, and *Windows NT* are registered trademarks of Microsoft Corporation.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Computer Corporation disclaims any proprietary interest in trademarks and trade names other than its own.

June 1999 P/N 9558P Rev. A02



Dell™ Dimension™ Systems Setup Guide

Before using this guide, connect your computer system according to the steps on the *Getting Started* sheet. Failure to properly connect your system may result in computer malfunctions or damage.

Operating System Setup

Your Dell system has been shipped with either the Microsoft® Windows® 98 Second Edition or Microsoft Windows NT® operating system already installed. Perform the steps in the section that corresponds to your operating system so that the software functions properly on your Dell system.

Microsoft Windows 98 Second Edition

Initial setup of Windows 98 Second Edition takes about 15 minutes. The setup process is customized according to which computer components you have.

NOTICE: To prevent possible conflicts with Windows 98 Second Edition, do not connect devices such as printers or install items such as expansion cards before you complete your Windows 98 Second Edition setup. These devices should only be connected or installed after the operating system setup is completed.

NOTICE: Do not interrupt the Windows 98 Second Edition setup process. Doing so may render your computer unusable. (Clicking the Skip buttons during the setup process is not an interruption of the process.)

NOTICE: If you experience problems and the system stops responding, do not use <Ctrl><Alt> to reboot your system. Instead, press and hold the power button for approximately 4 seconds to shut down the system. Then press the power button again to turn on the system. When prompted, select Safe Recovery Mode to continue the setup.

To complete the initial setup of Windows 98 Second Edition on your Dell system, perform the following steps:

1. If you have a modem installed in your computer, connect a telephone line to it as instructed in the *Getting Started* sheet that accompanied your system.

2. Turn on your system as instructed in the *Getting Started* sheet that accompanied your system.

The **Dell Software License** window appears.

3. Read the software license agreement that came with your system and then press any key to continue.

The **Important Technical Support Information** window appears and displays your Express Service Code.

4. Press any key to continue.

NOTE: Dell's Express Service Code may not be available in all countries.



5. Read the instructions in the **Complete the Dell Setup** window, and then press any key to continue.

The system restarts automatically.

NOTE: After the system restarts, the Windows 98 screen is displayed for about 1 or 2 minutes. Although it may appear as if no activity is occurring, the operating system is actually loading program files.



6. When the **Getting Started** window appears, verify that the regional and keyboard setup and layout settings are correct for your location; then click **Next**. Otherwise, click the appropriate settings and then click **Next**.

7. When prompted, enter your name and click **Next**.

If your system includes a modem, proceed to the next step. Otherwise, proceed to step 10.

8. A modem preparation window appears that allows you to connect to Microsoft and register your operating system. Click **Skip** and proceed to step 10, or enter the requested information and click **Next**.

A registration progress window appears while your modem connects to Microsoft.

9. To send the registration information to Microsoft, enter the requested information in the **Registration Confirmation** window and click **Next**. If you do not want the information sent, uncheck the **Please, send the information on this screen to Microsoft** box and click **Next**.

10. Read the license agreement, click **I accept the Agreement**, and then click **Next**.

If you do not accept the agreement, you cannot access Windows 98 Second Edition.

11. If a screen appears that prompts you to set up your Internet access or provides information about how to connect to the Internet, follow the instructions that appear on the screen or click **Skip** to bypass Internet setup and information. If no prompt appears, proceed to the next step.

12. Click **Finish**.

13. If the **Date/Time Properties** window shows the correct time and date for your area, click **Close**. Otherwise, enter the correct time and date, click **Apply**, and then click **OK**.

Windows 98 Second Edition is now set up and the Windows desktop appears on the screen.

14. If the IntelliMouse **Productivity Tips** window is open on the Windows desktop, read the window's contents. Click the **Show Tips at Windows Startup** box to uncheck it, and then close the window by clicking the **X** in the upper-right corner.
15. Double-click the **Complete Dell Setup** icon on the Windows desktop.



The Dell Setup program configures Dell-installed software, including virus protection, to work properly on your system. When it finishes, a dialog box instructs you to restart the system.



*NOTE: After the system restarts, the **Complete Dell Setup** icon no longer appears.*

16. Click **OK**.
17. Restart your system.

Click the **Start** button on the Windows desktop, click **Shut Down**, click **Restart**, and then click **OK**.

Windows 98 Second Edition is now completely installed on your system. Proceed to "Adding a Printer" for instructions on how to connect a printer and to "Information Resources" for descriptions of reference tools that are included with your Dell system.

Microsoft Windows NT

If you are on a local area network (LAN), check with your network administrator *before* setting up Windows NT for information relevant to the setup process, such as the system name, the administrator password, and required network protocols. Also attach the network cable (if applicable) and connect any devices you want to use with your system. For instructions, see the *Getting Started* sheet that accompanied your system.

NOTICE: Do not interrupt the operating system's setup process. Doing so may render your computer unusable.

Initial setup of Windows NT takes about 15 minutes. The setup process is customized according to which computer components you have. To configure Windows NT for your system, perform the following steps:

1. Turn on your system as instructed in the *Getting Started* sheet that accompanied your system.

The **Dell Software License Agreement** appears. It is important that you read and understand the license agreement. You must accept the agreement to proceed with the setup of your system.

2. Type *y* if you accept the Dell software license agreement.

The **Technical Support Information** window appears.

3. Type *x* to continue.

The system restarts and Windows NT prepares your system for setup.

The system restarts again and the **Select Operating System** window appears. No action is required at this screen.

4. Click **I Agree** to accept the Microsoft software license agreement.

As with the Dell software license agreement, it is important that you read and understand the Microsoft software license agreement.

You must accept the Microsoft software license agreement to proceed with the Windows NT operating system setup.

The **Windows NT Workstation Setup** screen appears.

5. Type your name (required) and organization (optional) and click **Next>**.

The **Registration** window appears.

6. Locate your Product Key as instructed in the *Getting Started* sheet that accompanied your system, type the Product Key (use the <Tab> key to change fields), and then click **Next>**.

The Product Key is the 20-digit number located on the Certificate of Authenticity.

The **Password** window appears.

7. Type your chosen password in the **Password** field and again in the **Confirm Password** field, and then click **Next>** twice.

The password can be up to 14 characters in length. A null password is acceptable if you do not want to use a password.



NOTE: The password controls access to your computer and should be stored in a safe place.

8. If you do not have a network interface controller (NIC) installed in your system, proceed to step 9.

If you do have a NIC installed, the **Windows NT Workstation Setup** window appears. Dell recommends that you click **Do not connect this computer to a network at this time**, and then click **Next>** and finish the Windows NT setup procedure. After Windows NT setup is complete, use the **Network** icon in the **Control Panel** to configure the network.

9. Click **Restart Computer** in the **Windows NT Setup Complete** window to reboot the system.

When the system restarts, you are prompted to select an operating system.

10. Select an operating system.

The options are **Windows NT WorkStation Version 4.00** (default) and **Windows NT WorkStation 4.00 (VGA Mode)** (normally used for troubleshooting). Use the up- or down-arrow key to highlight the desired option and press <Enter>. If no action is taken, the default (highlighted) is selected automatically after 30 seconds.

11. Press <Ctl><Alt> simultaneously at the **Begin Logon** window.
12. Type your password and click **OK**.

The **Welcome to Windows NT** window appears. You can click either of the following items for additional information, or you can exit from this window and begin working on the desktop:

- **What's New** — Learn about new features of Windows NT 4.0.
- **Help** — Use the search facility to find information on a particular subject, title, word, or phrase.

Creating a Windows NT Emergency Repair Diskette

The emergency repair diskette saves your original configuration and can be used to restore your system to its initial setup state if files become corrupted. It should not be used as a backup tool.

To create the emergency repair diskette, perform the following steps:

1. Click the **Start** button, point to **Programs**, and click the **Dell Accessories** folder.
2. Click the **Create Repair Disk** icon.
3. In the **Repair Disk Utility** window, click **Create Repair Disk**.
4. Label a diskette "Emergency Repair Disk," insert it into the diskette drive, and click **OK**.

The diskette is formatted and the configuration files are copied to it.

5. When the **Repair Disk Utility** window reappears, click **Exit**.
6. Remove the diskette from your diskette drive, and store it in a safe place.

Adding a Printer

NOTICE: To maintain a strong signal from the computer, use a bidirectional parallel cable measuring 10 feet or less. Longer cables may prevent the printer from operating properly.



NOTE: Most new printers provide installation CDs that run automatically when inserted in the CD-ROM or DVD-ROM drive. After you have completed the operating system setup, install the software for these printers by inserting the CD and following the instructions on your screen. It is not necessary to use the **Printer Wizard** to install these types of printers.

Some printers come with specific instructions for connection and installation of necessary software and drivers. Follow the instructions that came with your printer. If instructions are not available, perform the following general steps:

1. Turn off the computer and any attached devices.
2. Connect the printer cables.

Connect the data cable between the printer and the appropriate port on your computer. The parallel port with the printer icon is LPT1 and is the most commonly used printer port. The serial port, marked with "I/O," is the COM port. If you are unable to determine which port to use, contact the printer manufacturer.

Connect the power cable to an electrical outlet.

3. Turn on the printer, and then turn on the computer system.
4. If the printer is automatically detected by Windows, follow the instructions that appear.

If the printer is not automatically detected during operating system start-up, proceed to step 5.

5. Double-click the **My Computer** icon on the Windows desktop.
6. Double-click the **Printers** folder, and then double-click the **Add Printer** icon.
7. In the **Printer Wizard** dialog box, click either the **My Computer** option or the **Network Printer Server** option and then click **Next>**.
8. Click the serial (COM n) or parallel (LPT1) port that you want to use.

Choose the computer serial or parallel port to which you connected the printer. Verify that the port you chose is not already assigned to another device. If necessary, add a port or configure a port by using the buttons in the **Printer Wizard** dialog box.



NOTE: If you are connecting to a network printer, contact your network administrator.

9. Select the printer manufacturer and model from the list provided. If your printer is not listed and the printer drivers are on a diskette or CD, click **Have Disk...** and insert the diskette into drive A or the CD into the CD-ROM or DVD-ROM drive.
10. Provide the printer name (up to 31 characters) and click **Next>**.
11. Indicate whether the printer will be shared with other network users by clicking either the **Shared** or **Not shared** option.

If the printer will be shared, the **Connect to Printer** dialog box appears. Continue to step 12.

If the printer will not be shared, go to step 14.
12. Select your printer from the list provided or type the printer name. Then click **OK**.
13. Select all the operating systems (from the list provided) required to print to the shared printer.
14. Click **Next>** to continue.
15. Select **Yes** or **No** to indicate whether you want to print a test page. Then click **Finish**.

Information Resources

Dell provides a number of handy reference tools to help you make the most of your computing experience.

Online Help

The online system *Help* is an HTML help file that allows you to search for information in multiple ways. You can quickly link to information on the following topics:

- Hardware and software features of your system
- Options and upgrades
- The Windows desktop, where you can change your wallpaper and screen saver, create shortcuts, and position icons
- Software access, installation, and removal
- Basic file management, such as finding, copying, deleting, and renaming files
- Tips on using your computer hardware
- Power-protection devices, such as surge protectors, line conditioners, and uninterruptible power supplies (UPS)
- Answers to commonly asked questions about your computer system
- Phone numbers for contacting Dell for help



To open the *Help*, click the **Start** button, point to **Programs—> Dell Documents**, and click **Dell Dimension Systems Help**.



You may also double-click the **Dell Documentation** icon on the Windows desktop, click **System Information**, and then click **Dell Dimension Systems Help**.

Reference and Troubleshooting Guide

Your *Reference and Troubleshooting Guide* provides information on adding upgrades like memory, performing basic troubleshooting procedures, and reinstalling drivers. It also covers technical specifications, the system setup program, and system codes and messages.